

INSTRUCTIONS TO FIT YOUR NEW INNER CABLE

STEP ONE: REMOVE OLD INNER CABLE BY UNSOLDERING THE MALE INNER CABLE MOUNT. PULL THE OLD INNER CABLE OUT OF THE OUTER FLEX FROM THE HANDPIECE END. NOW UNSCREW THE FEMALE INNER CABLE MOUNT AWAY FROM THE HANDPIECE SHAFT. YOU WILL NEED TO LOCK THE SHAFT USING A TOMMY BAR THROUGH THE HOLES IN THE HANDPIECE BARRELL TO STOP THIS FROM TURNING.

STEP TWO: UNSOLDER THE MALE END ON THE NEW INNER CABLE THEN SCREW THE FEMALE MOUNT BACK ONTO THE HANDPIECE SHAFT THEN FEED THE NEW INNER CABLE INTO THE OUTER FLEX. AT THIS POINT IF THE INNER CABLE IS TOO LONG YOU MAY NEED TO CUT THE CABLE TO LENGTH. YOU MAY NEED TO GRIND / TIDY THE NEW CUT END THEN RESOLDER THE MALE INNER CABLE MOUNT. CHECK EVERYTHING IS TRUE AND IN ALLIGNMENT AND THEN REATTACH TO THE MOTOR.