

elma super clean

CLEANING CONCENTRATE FOR JEWELLERY

works gentle and brightens

Description

elma super clean is an aqueous, mild cleaning concentrate with ammoniac for the gentle cleaning and brightening of jewellery in immersion baths with or without ultrasound. Suitable for gold and silver and jewellery with hard stones. There is a brightening effect on precious metals and alloys, respectively.

Soft stones (for example turquoise, lapis, amber) have to be checked before use of *elma super clean*. When cleaning soft stones do not use ultrasound with frequency ≤ 50 kHz. Not suitable for corals!

Removes grease, sweat, emulsions, finger prints and dust.

Application and dosage

Dosage: 3 – 10 % when applied in an ultrasonic bath, cleaning time 3 – 5 minutes when used in ultrasonic bath at room-temperature.

Without ultrasound the cleaning time is longer with a required dosage up to 10 – 20 %. After cleaning, rinse thoroughly and dry.

Hotline for application consulting

Working days: Tel. ++49 (0) 7731 882-287. Email: chemlab@elma-germany.com

Safety recommendations

elma super clean is not classified as dangerous in accordance with EC directives / German regulations on dangerous substances. Observe the hints indicated in the Safety Data Sheet. Always handle chemicals with care.

Physical-chemical characterisation

Density: 990 – 1000 g/l, pH (concentrate): about 10 in state of delivery.

Ingredients according to Annex VII, A, EC-Regulation 648/2004 (detergents): <5% anionic surfactants, <5% non-ionic surfactants, <5% NTA, perfumes. Does not contain silicates or phosphates.

Disposal

The surfactants in our product meet the criteria for biodegradation as laid down in Annex III of the Regulation (EC) No 648/2004 on detergents.

The cleaning bath can be fed into the sewage system after neutralisation; check the contamination contained in the used cleaning bath (observe local sewage regulations).

Recommendation: use acetic acid or citric acid for neutralisation in an ultrasonic bath – do not use hydrochloric or sulphuric acid!

European waste code: 20 01 30, „detergents other than those mentioned in 20 01 29“.

Volumes, storage and transport

Available volumes: 250ml, 1l and 10l.

Store in closed original container only. Keep temperature between -5 and +30 °C.

Shelf life: 5 years from date of production (see stamp on label).

Classification for all means of transport: no hazardous material.

Elma Hans Schmidbauer GmbH&Co KG

Kolpingstr. 1-7, D-78224 Singen

e-mail: info@elma-germany.com

Tel.: ++49 (0) 7731 882-0

Fax: ++49 (0) 7731 882-266

www.elma-germany.com

08.02.08/ P:\Produkte\PRODInfo\Produkte\englisch\word\IP_super clean_GB.doc

