



# VARIABLE SPEED POLISHING MACHINE WITH EXTRACTOR 1/2HP



- Work indicator light
- Speed control knob



- Motor switch
- Light switch
- Dust extraction filter clip

# Product Use

## Setup & Preparation

Inspect the motor, polishing spindles, guards, and extraction system for damage or loose parts.

Ensure the extraction unit is connected securely and filters are clean.

Choose the correct polishing mop (stitched, loose leaf, sisal, etc.) for your stage (cutting, refining, finishing).

Mount the mop securely and check it spins true (no wobble).

Select the appropriate polishing compound (coarse, medium, fine).

Wear proper PPE:

Safety glasses or face shield

Respirator or dust mask (even with extraction)

Hearing protection

Apron and snug-fitting clothing

# HS WALSH & SONS

— SERVING JEWELLERS & HOROLOGISTS SINCE 1947 —

London  
020 7242 3711

Biggin Hill  
01959 543660

Birmingham  
0121 236 9346

[mail@hswalsh.com](mailto:mail@hswalsh.com) [www.hswalsh.com](http://www.hswalsh.com)